


Mobile DVB-T Receiver




USER MANUAL

V1.1

Table of Contents

STRUCTURE	-----3
INSTALLATION	-----3
MAIN MENU	-----7
1. OVERVIEW	-----7
1.1 Major Features	-----8
1.2 Playback Control	-----9
1.3 Supported Media Types	-----10
1.4 System Requirements	-----10
2. APPEARANCE	----- 11
2.1 Main Control	-----11
2.2 Advanced Panel	-----13
2.3 EPG Panel	-----14
2.4 Floating Panel	-----15
2.5 Right-Click Menu	-----16
2.6 Hot Keys	-----17
ACCESSORIES	-----18

STRUCTURE



INSTALLATION

Be sure the DVB-T USB STB is connected to your computer.


Execute the “Setup.exe” program from the CD.




Please select the user interface language that you want to install and click “OK” to continue.




Click “Next” to continue.



Please select “I accept the agreement”, and Click “Next” to continue.



Select an installation folder and click “NEXT” to continue. (Or click “Browse” to switch to an existing folder).



Select a shortcut folder and click “Next” to continue.



Click "Continue Anyway".



Click "Finish" to restart the computer.

A pop-up window saying "Found New Hardware Wizard" will appear.



Please Select "Yes" and click "Next" to continue..



Please Click “Next”, the driver will be installed automatically from CD. When a pop-up window saying “Found New Hardware Wizard” disappear.



Please Click “Continue Anyway”.



Click “FINISH” to complete the installation.



Enter registration information

Enter your name, E-mail, and the serial number for your copy of the program. The serial number is located on the outside of the CD case, or on the receipt page for web purchases. You can also locate the serial number for web purchases in your online order history.

User Name :

E-mail :

Serial Number :

Please fill the registration information. (You can fill your own user name and email; For serial number, please find it in the disc)



Register Succeed

Thank you for Registering BlazeDTV, please relaunch to enjoy the unlocked BlazeDTV.

Register successfully, press ok.

MAIN MENU

1. OVERVIEW



HDTV Player is a full-featured and easy to use HDTV player software, combining HDTV playback, FM receiving, video record and DVD playback functions. You can make advantage of PC monitor's high resolution, watch, record, playback high definition HDTV program or teletext broadcast program.

HDTV Player has wide compatibility, running stably and smoothly on Windows 2000/XP operating system.

Now, start to experience the HDTV Player!

- Major Features
- Playback Control
- Supported Media Types
- System Requirements

1.1 Major Features

Advanced HDTV Playback Features:

- Auto scanning channels and save all channels
- Support Electronic Program Guide(EPG) navigation
- Live update and forecast HDTV Program
- Support multi-channel preview, easily access target channel
- Support Time Shifting function
- Check programs info, such as service provider, channel frequency, service type, etc
- Notify current program's duration time, the start time and the end time

Support Multiple Real-time & Schedule Task:

- Real-time record and save your favorite program while watching HDTV program
- Schedule record HDTV program, never miss any wonderful programs
- Schedule watch program at specified time
- Real-time capture favorite video as still image

Manage HDTV Programs:

- Freely manage favorite program list

- Support Parental Control

Support Multiple Source Files Playback:

- Compliant with DVB-T based protocol
- Playback picture as slide show
- Support Teletext broadcasting
- Support MPEG-2 decoder

Outstanding Video & Audio Quality:

- High video quality, support multiple aspect ratio and video hardware accelerating
- Video desktop lets you view video in true background mode, just like wallpaper
- Smart stretch lets video smart fit on all monitor with different aspect ratio, avoid video loss or distortion

Enhanced audio effect and equalizer, supports 5.1, 6.1, 7.1 channel output

1.2 Playback Control

Playing HDTV	
Scanning Channels	Multi-channel Preview
EPG Guide	Time Shifting
Realtime Record HDTV	Capture Image
Schedule Record HDTV	Schedule Watch HDTV
Add to Favorites	Playlist Control
Forecast Next Program, Live Update Program List	Teletext Broadcasting
Multi-subtitle	Multi-audio
Video Control	
Zoom in or Zoom out	Full Screen Playback
Desktop Video	Wide Screen, Letter Box, Keep Aspect Ratio, Smart
Color Adjustment	Freely Adjust Video Window Size
Visualization (Playback Audio File)	
Audio Control	
Audio Adjustment	Mute On/Off

Equalizer Control	Special Audio Effect
Playback Source	
Playing HDTV	Playing DVD/VCD/CD disc
Play DVD from Hard Disk	Play Media Files
Play External Video Device	Play Photos as Slide show
Open Playlist	
Playing DVD	
Select DVD Menu: Title, Chapter, Subtitle, Audio,	Record DVD Video/Audio
Capture Image	Book Mark Playback
2X, 4X, 8X, 16X Fast Forward/Fast Backward	Step Forward
Playlist Control	Repeat Title/Chapter
Eject/Close DVD Disc	
Time Control	
Drag Slider bar to Desired Time	Play at Time

1.3 Supported Media Types

- **Video file formats**
 - Motion Picture Experts Group (MPEG, MPG, M1V, DATMPA, MPE, MPV2)
 - Video Object File (VOB)
 - MPEG 2 VIDEO (M2V)
- **Audio file formats:**
 - MPEG Audio Layer-3 (.MP3, .MP2, .MP1, .MPA, .M2P, .M2A)
 - CD(CDA)
 - Ogg Audio(OGG)

1.4 System Requirements

	Basic
CPU	Intel Celeron 600MHz or higher
System Memory	128MB RAM or higher
Operating System	Windows 2000, Windows XP
Display card	Have 24 Bits resolution and support DirectX, 8MB Video-ROM or more
Sound card	PCI sound cards, Integration chipset on Mother Board, USB audio devices etc. compatible with Windows and

	stereo speakers
Hard-disk available capacity	At least 512 MB temporary disc space for TimeShifting function; Large enough space for HDTV program or DVD record
DirectX	DirectX 9.0 or later

2. APPEARANCE

HDTV Player Appearance

HDTV Player is designed with user-friendly interface, the default video window and main control are as below:



- Main Control Panel
- Advanced Panel
- EPG Panel
- Floating Panel
- Right-click Menu
- Hot Keys

2.1 Main Control

Appearance Introduction

















Startup HDTV Player and keep the active status.













Main Control Panel when playing HDTV:





Note: When playing DVD, not each section is fit to all DVD's titles. Only manufacturers can confirm the specific functions burned on discs. The functions which are unavailable to special titles will be displayed gray and not able to be accessed.

The following descriptions are about the sections on control panel:

Button/Icon	Name	Description
	EPG	Open EPG window for HDTV playback
	Play	Play HDTV or Media
	Pause	Time Shift during the HDTV playback; or pause during the DVD playback.
	Stop	Stop the current playback. Click play to restart playback.
	Record	Record HDTV or DVD file
	Previous	Skip to previous HDTV channel or DVD chapter to play
	Browse	Browse channel
	Next	Skip to next HDTV channel or DVD chapter to play
	Open	Select playback type
	Subtitles	Select Subtitles. Select language caption when there are multiple language captions.
	Audio	Select Audios: Click to select audio if there are various Audio options
	Capture	Capture video as .bmp still image
	Volume Control	Drag slider right/left to increase/decrease volume.
	Mute	Click it, the audio is muted, click once again, get back The previous conditions.
	Media Type	Display current media type, vary with different media type
	Playback status	Display current playback status, vary with different Playback status

	Signal Quality	Display HDTV signal quality (Available when playback HDTV)
	Signal Strength	Display HDTV signal strength (Available when playback HDTV)
	Channel/chapter	Display current HDTV channel or DVD chapter info
	time	Display hours, minutes, seconds of the current HDTV time or DVD chapter time
	Fast backward	Fast backward, switch between 1X, 2X, 4X, 8X, 16X at each press
	Slider bar	Drag the slider to new position for playback.
	Fast Forward	Fast forward, switch between 1X, 2X, 4X, 8X, 16X at each press
	Open Floating Panel	Show Floating Panel
	Show Advanced Panel	Show/Hide Advanced Panel
	Minimize	It is a standard windows icon. Click it, the control panel And the view window will be minimized and displayed as icons on system toolbar.
	Help	Access the online help.
	Exit	Exit BlazeVideo HDTV Player.

2.2 Advanced Panel

Click  on Main Control Panel to show "Advanced Panel" or click  to hide it,









which has six sub panels:

Default open with TV advanced panel:





Click to show TV advanced panel.

1.  Scan: Click to scan channels.
2.  Recall: Click to return to last channel
3.  Favorite: Click to add current channel in favorite list.
4.  Teletext: Display teletext
5.  Previous: Skip to previous page of the teletext
6.  Next: Skip to next page of the teletext
7.  display total and current teletext page info
8.  Save current page of teletext as a .txt file.



Click to show DVD advanced panel.



Click to show color advanced panel.



Click to show equalizer advanced panel.




Click to show zoom panel.







Click to show screen panel.

2.3 EPG (Electronic Program Guide) Panel


HDTV Player provides with Electronic Program Guide(EPG), through which you can scan channels, preview channel, access program guide, check all programs info, manage favorites and create schedule task.



There are four sub windows in EPG window, you can click the four buttons at the bottom of EPG window for your desired operation:

1.  Show Transport: scan channels, refresh channels and access all channels properties.
2.  Show Guide: access program guide.
3.  Show Favorite: manage favorite programs.
4.  Show Schedule: create task, including schedule record and schedule watch.

2.4 Floating Panel

Click  button on Main Control Panel, or right click Video Window, select "Show Floating Panel" to open Floating Panel. Here you can access more advanced functions and operations.



There are four sub pages in Floating Panel:



Show Playlist.



Show Bookmark.



Show Capture.



Show Record.

2.5 Right-Click Menu

During playback, position the cursor above the video window to right click for the menu, the menu's commands is same of general menu. The menu is followed:

✓ Play	Play:start playback
Pause	Pause:pause/continue playback
Stop	Stop:stop playback
Fast Forward	Forward:playback DVD under the fast forward mode
Fast Backward	Backward:playback DVD under the fast backward mode
Go to	Go to:jump to certain title/chapter/time
Repeat	Repeat:repeat the current chapter/title
Menu	Menu:select available options from the current DVD disc (root, language, captions etc.)
Title	Title:display the current HDTV frequency or DVD title
Chapter	Chapter:display the HDTV channels or current DVD chapter
Subtitle	Subtitle:select caption language
Audio	Audio:select audio options
Angle	Angle:select camera angle
Play from	Play from:choose the source for playback
Bookmark	Bookmark:mark your favorite scenes
Capture Image	Capture Image:capture your favorite scenes
Visualization	
Video Window	
Full Screen	
Show Floating Panel...	
Options...	
Purchase & Register	
Help	
Exit	

Visualization:	Switch different visualization
Video Window:	Select different video window
Full Screen:	zoom in the video window to your monitor's available area
Show Floating Panel:	show Floating Panel or bring the Floating Panel to top
Options:	open the Options dialog for change settings
Purchase & Register:	purchase or register BlazeVideo HDTV Player
Help:	access online help
Exit:	exit BlazeVideo HDTV Player

2.6 Hot Keys

For user's operating convenience, HDTV Player provides a lot of keyboard express keys, the express keys is active when the cursor is over the video window.

Two keys indicate holding the first key and pressing the second key or pressing the two keys at the same time. Non-letter key is put in bracket. The Express keys include:

Functions	hot-keys	Functions	hot-keys
Angle	G	Stop	End
Audio	A	Pause	Space
Chapter	C	Fast forward	F
Reduce brightness	-	Fast backward	B
Increase brightness	-	Bookmark	K
Reduce volume	alphanumeric keyboard "-"	Capture	[Ctrl] + C
Increase volume	alphanumeric keyboard "+"	Title menu	T
Ejecting disc	-	Subtitle menu	S
Exit HDTV Player	-	Main menu	R
Next channel/chapter	PgDown	Mute on/off	M
Previous	PgUp	Step forward	N

channel/chapter			
Adjustment	-	Switch between the full screen mode and the window mode	Z
DVD menu selection in four directions	Corresponding Directional Arrows	Enter DVD Menu	Enter
Attribute page	-	Resume	U

ACCESSORIES

Antenna, CD Driver, User Manual